



## LexJet WR Window Graphic Film

### Installation Guide

#### Tools:

- Non-abrasive glass cleaner
- A soft-edged squeegee, preferably something utilizing Suede Teflon on one edge
- Lint-free cloth
- Masking tape, if you prefer to hinge your graphic prior to installation (3M #234 is a good quality tape that works great for hinging graphics)

#### Installation:

1. Clean application surface, depending on the size of your graphic. It may be a good idea to clean the surrounding area to simply help

prevent dust and other small debris from contaminating your graphic.

2. Tack your graphic in place with a few small pieces of low-tack masking to ensure both sizing and placement.
3. Use a horizontal strip of masking tape to hold the graphic in place from the top.
4. Peel the liner back a few inches from the top, squeegee that section of the graphic down, and then progress in the same way a few inches at a time.

*Note: This type of media can mar with improper handling and installation technique.*